


CODING

-371001
-371002



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS


nesthouz.com

Read the instruction carefully. Remove all the wrapping material, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubber mat to prevent from scratches.

Caution


KEEP ALL PARTS OUT OF REACH OF CHILDREN.

ITEM	HARDWARE LIST	QTY
Ⓐ	JCBC SCREW M6 X 60MM 	8
Ⓑ	SPRING WASHER 5/16" 	8
Ⓒ	FLAT WASHER 5/16" 	8
Ⓓ	ALLEN KEY M6 	1
Ⓔ	SCREW M3.5 X 16MM 	1
Ⓕ	SCREW M3.5 X 25MM 	1
Ⓖ	PLASTIC HOOK 	2
Ⓗ	CABLE TIE 	1
Ⓘ	FLAT WASHER (ø5 X ø9) 	2
Ⓙ	WALL PLUG 	1
Ⓚ	HANDEL 	3
Ⓛ	SCREW M3.5 X 16MM (BLACK) 	6

ITEM	PART LIST	QTY
①	BODY 	1
②	TABLE LEG 	4

CODING

-371001
-371002



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

nesthouz.com

